

CORD-LESS Teth-Air

Using a small Phillips screw driver, remove the screws from the back of the Teth-Air Transmitter Tag. Insert the provided CR2032 battery with positive (+) toward the circuit board., Use silicone sealant around the edges of the case and in the screw holes to prevent moisture contamination. Install Teth-Air label and wrist strap as per the instruction sheet.



Start the machine to power up the Teth-Air. The engine should die in 1 second. This proves the operation of the system. Now re-start the engine while holding the blue button (or push and hold within 1 second of starting). The engine should remain running with the LED solid green, this will be the By-Pass Mode. Release and press the button a second time with the tag near-by and the Teth-Air Receiver will scan and record the unique code of up to 6 Tags. Your Teth-Air is now programmed.