

GRIPPER RIPPER SKI BRACE



Designed to strengthen the Polaris Gripper Ski mount and reduce wear.




www.sourceinnovations.ca

403-444-5457



Step 1: Remove the ski and position the brace over the exterior of the ski mounting hole. Match the angle of the cutouts with the webbing internal to the ski as there is a front and rear of the brace.

Step 2: Insert the bushing from the outside. And clamp in place.



Step 4: Now remove the brace and re-drill only the outer holes with a 3/8" drill.

Step 5: Grease the bushing and reinsert it from the inside of the ski.



Step 3: With the brace top parallel with the curvature of the top of the ski, drill the 2 holes all the way through with a 17/64" drill.



Step 6: Insert the provided bolts and tighten. Note these bolts only need to be snug. The compression of the plastic will lock them from backing out. Step 7: Do the same for the other side of ski and then re-install the ski.